


How to guide PRIVATE LOCKING


Keep your valuables secure with Private Locking, a standard feature fitted to all TX taxis.

The Private Locking function works a bit like the safe in your hotel room; simply enter a passcode to securely lock the boot compartment. Once activated, it is impossible to access the boot compartment, even if the vehicle key is present.


This function provides additional peace of mind when leaving valuables in the vehicle, particularly if it has been left in the care of a third party, such as at a car wash or car parking service.




- 1 To activate Private Locking, open the **Settings menu** from the touchscreen.




- 2 Choose **'My Car'...**




- 3 ... then **'Locking'**



- 4 and select **'Private Locking'**.



- 5 Set a **memorable passcode** and select **'Confirm'**. A new passcode is set each time the function is activated.



- 6 When **Private Locking** is activated, a tick will appear in the status box.



Forgotten your passcode?

If Private Locking has been activated and you have forgotten your passcode, please contact an LEVC dealer.



- 7 The boot may now **only be opened** by selecting 'Private Locking' and re-entering your passcode and cannot be opened with the remote fob. It is therefore very important that you **commit your passcode to memory**.

