

OPENING THE SIDE DOOR ACTIVATES SIDE STEP.  
A PULL-DOWN HANDLE ENSURES SAFE ENTRY.

MEDIC SEATS TURN AT A 45 AND 90 DEGREE ANGLE  
IN ORDER TO TEND TO ADJACENT PASSENGERS

VEHICLE ACCOMODATES 2 WHEELCHAIRS.  
2 PASSENGER SEATS BEHIND DRIVER.  
3 PASSENGER SEATS PARALLEL TO MEDIC SEATS.



TO RELEASE CHAIRS, RAISE THE RED SHOOT BOLT  
AND AT THE SAME TIME, PULL THE RED LEVER

TAIL LIFT IS RELEASED BY PUSHING DOWN THE  
YELLOW HANDLE

THE MIDDLE BUTTON ON THE CONTROLLER  
ALLOWS RAMP TO COME FULLY OUT

YELLOW HANDLES ON TAIL LIFT ARE UNFOLDED.  
THEN BOTTOM BUTTON ON  
CONTROLLER LOWERS THE RAMP.

TOP BUTTON ON CONTROLLER RAISES THE  
TAIL LIFT TO THE HEIGHT OF THE VEHICLE

HEADREST ATTACHES TO MEDIC SEATS FOR USE OF  
WHEELCHAIR PASSENGERS. WHEELCHAIR  
RESTRAINTS SECURELY HOOK TO THE WHEELCHAIR.



## FIAT DUCATO MAXI WHEELCHAIR ACCESSIBLE PASSENGER TRANSPORT VEHICLE



**Vic Young (South Shields) Ltd**

Newcastle Road, South Shields, Tyne and Wear, NE34 9QE tel: 0191 427 1566  
www.vicyoung.co.uk email enquiries: conversions@vicyoung.co.uk





EASY ACCESS TO FIRST AID KIT

LED LIGHTS PROVIDE POWERFUL LIGHT SOURCE  
WHEN TRAVELLING AT DARK HOURS

USB PORTS THROUGHOUT VEHICLE WITH LED  
LIGHT TO INCREASE VISIBILITY AT DARK HOURS



AIR CON SYSTEM ALLOWS TEMPERATURE  
REGULATION TO SUIT THE NEEDS OF PASSENGERS

POWERFUL LED LIGHT AT REAR ASSISTS  
WHEELCHAIR USER ENTERING VEHICLE

AUXILIARY BATTERY ENSURES CONSTANT POWER  
TO AIR CON SYSTEM, LED LIGHTS & USB PORTS



## FIAT DUCATO MAXI WHEELCHAIR ACCESSIBLE PASSENGER TRANSPORT VEHICLE



**Vic Young (South Shields) Ltd**

Newcastle Road, South Shields, Tyne and Wear, NE34 9QE tel: 0191 427 1566  
www.vicyoung.co.uk email enquiries: conversions@vicyoung.co.uk

